

# GROUND ROD DRIVERS

## UTILITY & POLE PULLING EQUIPMENT



### FAST, EFFICIENT GROUND ROD INSTALLATION

- Designed with a positioning guide which allows the driver socket of the rotary hammer to be engaged to the ground rod driver
- Four ground rod driver choices:
  - Combined ground rod driver for 1/2", 5/8" and 3/4" diameter ground rods (Yellow)
  - For 1/2" diameter ground rod (Blue)
  - For 5/8" diameter ground rod (Red)
  - For 3/4" diameter ground rod (Green)
- Position at any height for easy and safe installation
- Manufactured from high quality steel, designed with a backside support ridge
- Safely install rods from ground level
- No rod damage, easily connect ground clamps



Part Number	Description
RD-UNI	(1/2", 5/8", 3/4") Universal Ground Rod Driver (Yellow)
RD0012	1/2" Diameter Ground Rod Driver (Blue)
RD0058	5/8" Diameter Ground Rod Driver (Red)
RD0034	3/4" Diameter Ground Rod Driver (Green)
RDSKT	Ground Rod Driver Socket (SDS-Max Shank)
Ground Rod Driver does not include drive socket or rotary hammer. Designed for use with rotary hammer. Use of impact tools or jack hammer may shorten service life.	